



## HID BALLAST KIT WIRING DIAGRAMS


1 - Low Watt MH/HPS QV




2 - 175-1500W MH QV




3 - Low Watt HPS




4 - 250-1000W HPS QV




5 - 250-1500W MH 480V




6 - 250-1000W HPS 480V




7 - 320-400W Pulse Start MH




8 - 5-Tap MH



9 - 5-Tap HPS




Photocontrol




## FLUORESCENT BALLAST WIRING DIAGRAMS


1 - Rapid Start




2 - Slimline 120V



3 - Slimline 277V



4 - High Output



Atlas Lighting Supply

2828 S. Linwood St

Visalia, CA 93277

Ph: 559-804-1664, F: 888-605-2324

www.atlaslightingsupply.com