

EP228PS/MV

Ballast Type: Electronic & Electromagnetic
 Compact Fluorescent Kit
 Starting Method: Programmed Start
 Lamp Connection: Series
 Input Voltage: 120-277V
 Input Frequency: 50/60Hz

ProFormance[®]
Electronic & Electromagnetic
Compact Fluorescent
Ballast Specifications

Lamp Type	# of Lamps	Volts	Rated Lamp Watts	Min. Start Temp (°F/°C)	Input Current (Amps)	Input Power (Watts)	Ballast Factor	THD %	Power Factor	B. E. F.	Wire Diag.
F28T5	2	120	28	0/-18	0.55	66	1.03	<10	0.98	1.56	36
		277			0.24						
F28T5	1	120	28	0/-18	0.29	34	1.04	<15	0.96	3.06	37
		277			0.13						
F21T5	2	120	21	0/-18	0.42	50	1.04	<12	0.97	2.08	36
		277			0.19						
F21T5	1	120	21	0/-18	0.22	26	1.03	<15	0.95	3.96	37
		277			0.10						
F14T5	2	120	14	0/-18	0.28	34	1.06	<15	0.96	3.12	36
		277			0.12						
F14T5	1	120	14	0/-18	0.16	19	1.15	<15	0.90	6.05	37
		277			0.08						

WIRING DIAGRAMS

OCV: 332V

CASE DIAGRAM

CASE DIMENSIONS

Overall (L)	Width (W)	Height (H)	Mounting (M)
16.90"	1.20"	1.00"	16.00"

Actual performance can vary depending on operating conditions. Specifications are subject to change without notice. All specifications are nominal unless otherwise noted. PN# 50166

